



Thermistor brown wires to be connected to the amplifier
operating voltage = 2,5V

V-W = Starting Wire
U-W = Running Wire
Rst > Rrun

PS : the real value of the condenser depend of the plant.
we suggest the operator to verify this.